








# PROGRAM TABLE








EFWT 1091G WP

	Program	Description	Capacity (KG)	Duration (min)	No. of Rinse	Spin Duration (min)
	Normal	Normal dirty clothes	10	Depending on load	2	6
	Jeans	Denim materials	4	55	2	6
	QuickWash	Slightly soiled clothes	3	27	1	3
	Baby	Children's clothes	7	65	3	6
	Delicate	Gentle washing of fine fabrics	3	31	2	2
	Heavy Duty	Heavily soiled clothes	7	Depending on load	2	8
	Blanket	Large household textiles	4	67	3	8
	Tub Clean	Wash the tub to keep the freshness	0	120	1	3
	Rinse & Spin	Extra spin and rinse step	10	34	2	6



# PROGRAM TABLE

EFWT 1091G WP

	Program	Description	Capacity (KG)	Duration (min)	No. of Rinse	Spin Duration (min)
	Normal	Normal dirty clothes	12	Depending on load	2	5
	Jeans	Denim materials	4	55	2	5
	QuickWash	Slightly soiled clothes	3	28	1	3
	Baby	Children's clothes	7	65	3	5
	Delicate	Gentle washing of fine fabrics	3	32	2	2
	Heavy Duty	Heavily soiled clothes	7	Depending on load	2	8
	Blanket	Large household textiles	4	68	3	8
	Tub Clean	Wash the tub to keep the freshness	0	120	1	3
	Rinse & Spin	Extra spin and rinse step	12	34	2	5